


GUI Notes on BMI Calculator

The is a simple form consisting of **three Labels**, **two TextBoxes**, a **Button** and one **GroupBox** containing two **RadioButtons**.



Initial GUI form – Design view

The Label with text, **Body Mass Index Calculator**, has the following properties set:

BackColor – Button Highlight

Border Style – Fixed 3D


Font: Size – 14; Bold – True

All other controls have their **Text** property set to **Font: Size – 12; Bold – True**

Be sure to place the **GroupBox** on the form first before adding the **RadioButtons** to it.

When the program starts, note that the **GroupBox** with the heading “**AnotherCalculation?**” is not visible. See next screenshot on page 2.

Add all of the controls before adding event handlers to various controls to perform the required functionality.




GUI form at start of execution

Do not associate any event handler with the two TextBoxes used to input the weight and height, but rely on the “**calculate BMI**” **button click** event handler to initiate checking the values in each of the text boxes are acceptable values.

If either input is not numeric or not in the acceptable range an appropriate error message is displayed using a **MessageBox**. See screenshots last page.

If the measurements are acceptable then a **MessageBox** is displayed showing the appropriate risk level message.




MessageBox displayed as a result of Button click and the measurements are above their respective lower limits

Clicking **OK Button** returns to the form with the **GroupBox** visible, the two **TextBoxes** and the **Calculate BMI** button are not enabled – screenshot next page.

The screenshot shows a Windows-style application window titled "Body Mass Index". Inside the window, the title "Body Mass Index Calculator" is centered at the top. Below this, there are two input fields: "Weight (kg)" containing the value "81" and "Height (m)" containing the value "1.75". A "Calculate BMI" button is positioned below these fields. At the bottom, there is a section titled "Another Calculation?" with two radio buttons labeled "Yes" and "No". The "Yes" radio button is selected.

Selecting the **YES** returns the form to its original starting state (screenshot page 2).

Selecting **No** will terminate the program.



The following Messageboxes show typical error messages when the weight or the height are not above their respective limits or when a value is either not a double or no value has been entered.

